




EAST ELEVATION

SCALE 1/8" = 1'-0"




SOUTH ELEVATION

SCALE 1/8" = 1'-0"



WEST ELEVATION

SCALE 1/8" = 1'-0"



NORTH ELEVATION

SCALE 1/8" = 1'-0"